

SUMMING THE LOW OUTPUTS OF CHANNEL ONE AND TWO.

1. Locate the 2 pin low summing connector on each channel.
2. Remove the black shunting block.
3. Locate pin 2 of each connector. (pin 2 is on the left looking from the front panel)
4. Solder a wire from pin 2 of channel A to pin 2 of channel B.
5. Half of the signal from each channel will now feed both Low outputs.
6. Reinstall cover.

