



STEREO 2-WAY MODE

LOW 1 = LOW OUTPUT
 HIGH 1 = HIGH OUTPUT
 FREQ 1 = HIGH/LOW XOVER PT
 CHANNEL 1,2 IDENTICAL



MONO 3-WAY MODE

LOW 1 = NOT USED
 HIGH 1 = HIGH OUTPUT
 FREQ 1 = HIGH/MID XOVER PT
 LOW 2 = LOW OUTPUT
 HIGH 2 = MID OUTPUT
 FREQ 2 = MID/LOW XOVER PT